

SAFEPLAY Paweł Niewczas - www.safeplay.pl / info@safeplay.pl



## Maintenance 7.

Maintenance
We remove impurities on an ongoing basis using a soft brush or a vacuum cleaner.
If, due to weather conditions, an organic tarnish or moss appears on the surface, it is recommended to clean it with water using a garden washer, without the use of chemicals. Attention! The water pressure must not be too high. The distance from the water jet to the surface should be at least 20 cm, and the water temperature should not exceed 60 °

## 8. Device control



SAFEPLAY Paweł Niewczas - www.safeplay.pl / info@safeplay.pl

AFEPLAY

